

KUNDENMASSTABELLE STRICKFLEECE JACKE

MAßTABELLE		HAMMER WORKWEAR STRICKFLEECE JACKE									
	NORMAL / <i>NORMAL</i>	XS	S	M	L	XL	XXL	3XL	4XL	5XL	Toleranzen
A	Oberweite / <i>chest</i>	96	104	112	120	128	136	144	152	160	+2 / -2
B	Saumweite / <i>bottom</i>	92	100	108	116	124	132	140	148	156	+2 / -2
E	Rückenlänge / <i>center back length</i>	71	73,5	76	78,5	81	83,5	86	88,5	91	+2 / -2
G	Obere Ärmellänge / <i>over sleeve length</i>	59,8	61,4	63	64,8	66,6	68,4	70,2	72	73,8	+2 / -2

