



E-Mail: kundendienst@roro-online.com www.roro-online.com

Table of language codes and corresponding translation titles for assembly instructions in various European languages.

Main assembly instructions table with 18 columns (DE, EN, HU, SL, SR, SQ, BG, CS, BS/HR, ES, FR, IT, MK, PL, RO, RU, SK) and 8 rows (1-8) of step-by-step instructions with corresponding images.

